



How To Apply Auto Correct Photo Image Quality

GX Print Server for
PrimeLink™

Version 1.0

Overview

This exercise will demonstrate the ability to automatically enhance photographic images using the GX Print Server. This feature can be used to apply improvements such as colour correction and sharpness to images. It can be used to enhance output quality without specialised graphic reproduction knowledge being required from the operator.

Objective

By the end of this exercise users will be able to:

- Navigate to the location of the setting on the GX Print Server
- Make an adjustment to the default value
- Compare the results

BEFORE



No Enhancement

AFTER



Emphasize Image Vibrancy

Auto Correct Photo Image Quality




Print a sample file with the default setting before making the following adjustment.

1. In the shortcut area, select **[Import Jobs]**.




2. Select sample jobs to import
3. Select **[Hold]** in [Operation After Importing] and **[template_default]** in [Template] and then click **[OK]**.




4. Double-click the imported job to display the job properties.


5. Select **[Job Settings] > [Color] > [RGB(Photo)]**.



6. Select **[Auto Correct Photo Image Quality]** Check box and select **[Emphasize Image Vibrancy]** in [Texture Correction]



7. Click **[Print]** to print.



Review the results of your print sample. You may also change a combination of the other settings such as Photo Type and Saturation to improve the overall color result.

Congratulations you have now completed this exercise.